



Contents:

- 2 x rails with attached drain valves and pivoting rods.
- 6 x clamps (8 clamps on long bed trucks)
- 4 x clear drain tubes.
- 2 x elevator bolts with star headed knobs & washers.
- Tools required: 1 x 15mm wrench or socket wrench.

STEP 1: Clamp on your rails.

Attach your rails to the inside lip of your truck bed rails using three clamps on each side. If your truck bed is 8' long, use 4 clamps per side. Make sure the rails are as far forward as possible.



Interesting tips:
Simply lock your tailgate and your cover is completely locked.

Strong enough to withstand 300 lbs. of evenly distributed weight.

STEP 2: Position cover on rails:
Position cover firmly on rails as shown. Make sure the latches catch under the rails as you do so.



Then fold the first panel over so that it fits snugly inside the bed. The rubber seal should make contact with the bulk head rail of your truck bed.

STEP 3: Insert elevator bolts through front panel of the cover. The bolts will pass through the slotted extension plates attached to your rails.



Outstanding weather resistance ensures that your cargo remains dry and secure, even in the most torrential conditions.

Allows 100% access to stake pockets & works with rails, tie downs and bed protection.

STEP 4: tighten elevator bolts under cover with the provided star headed knobs. Make sure you position the rubber washer on first, then the steel washer and then the knob.



STEP 5: fold cover shut to ensure a proper fit. Adjust if necessary.



STEP 6: Connecting drain tubes:
Your truck has holes inside the stake pocket posts and plugs against the cab wall. Simply attach your drain tubes to the valves in the corners of your rails and run them out of the existing holes or plugs as shown. If you have a bedliner, simply run the tubes behind the bedliner.

