



Installation Instructions



ProCaps are the most precise form fitted bed rail protectors you can get ProCaps are Made in the USA from durable impact resistant ABS plastic and CNC machined to ensure the most precise fit possible. ProCaps are available for over 80 models of trucks with or without stake pocket holes.

ProCaps are durable and will stand up to heavy abuse. They are perfect for work trucks or prior to installing camper shells & tonneau covers. ProCap's form fitted design allows for the most accurate install & provides durable paint protection under the heaviest abuse.



1. Ensure the label on the end of the box matches your truck.



2. Clean off any surface wax with alcohol and let it dry.



3. Prefit the parts to see where they will fit when you do final install.



4. Remove the red protector from the 3m tape on the TOP surface ONLY



5. On the sides, partially peel (dog ear) tape so it can be easily accessed from the bottom of the rail



6. Set the ProCap straight down on the truck bed rail. Set alignment before sticking down.



7. Pull down on the 3 dog ears along the inner rail. Pull the cap away slightly to allow easy removal



8. Do the same along the outer rail and make sure to apply pressure for the tape to take hold

Install the matching tailgate protector using the same method

- 9. Remove tape along the top mounting surface
- 10. Align the tailgate cap and push it straight down in place check for equal spacing on each side before sticking down
- 11. Remove the tape along edge apply pressure so tape holds



9.



10.



11