

# WeatherTech®

## TechShade® Installation Instructions



### WARNING

Never operate the vehicle with the TechShade® installed in the windshield. It is only intended for parked vehicle use.



1. Remove your TechShade® from the carton and unroll to install on your windshield. Please note that the cutout in the center is for clearance around the rear view mirror.



Warm  
Temperature



Cold  
Temperature

2. For protection against the sun and interior heat, please install the reflective material mirror-side facing outward. For colder temperatures, please install with the black side facing outward to absorb the sun's rays.



3. When not in use, simply roll the TechShade® up and secure the Velcro® tabs when not in use.

### HELP!

If you have any questions regarding installation or use of your WeatherTech® product, please call our Customer Service Department at (630) 769-1500, Monday through Friday, 9 a.m. to 5 p.m. Central Time. We want to help you get the most out of your new WeatherTech® product.

1 MacNeil Ct. • Bolingbrook • IL • 60440  
(630) 769-1500 • (800) 441-6287 • fax (630) 769-0300  
[www.weathertech.com](http://www.weathertech.com) • [sales@weathertech.com](mailto:sales@weathertech.com)

